

SRS MV 70 UNIVERSAL VIDEO MONITOR

...IMPORTANT...

If you are fitting an SRS system ONLY use these instructions (plus instructions provided with the SRS panel) otherwise use BITRON instructions provided.

NOTE: AN SRS SYSTEM USES 9007 & 9008 POWER SUPPLY AND SRS DOOR ENTRY PANEL.

INSTALLATION (WALL MOUNTING)

- 1 Fix the bracket to the wall so that the cable coincides with the cable entry hole. The base of the unit should be approximately 1300mm - 1305mm from floor level.
- 2 Open the phone (AN7320 or AN7577) by prizing apart with flat blade screwdriver in slots where front and rear cases meet.
- 3 Fix the phone to the bracket with the screws supplied.
- 4 Insert the interface card (MV70) so that the edge connector protrudes through the slot in the phone. Secure with screw provided.
- 5 Remove the protection cap on the monitor to allow the edge connector into the monitor case.
- 6 Hook the monitor onto the bracket and slide towards the phone, until it "clicks"
- 7 Make the connections to the phone terminals and MV70 card as shown on the relevant wiring diagram.
- 8 Replace the phone cover and hook up the handset.